

Eco Tension Assembly Instructions



design | display | print | signage

Eco Tension Assembly Instructions

1



Remove contents from carry bag.

2



With pole hole facing upwards, insert stabilising foot into rear of bottom horizontal rail.

3



Insert locking pin through holes in horizontal and stabilising foot to secure.

4



Assemble pole sections, ensuring that the bottom, middle, and top are the correct configuration.



5



Fully insert bottom of assembled pole into outer hole in stabilising foot.

6



Unroll graphic and hook slot, labelled 'Insert', over metal lip at top of pole. This completes the assembly.

